

RG4-INSULATED INSTALL INSTRUCTIONS 27" AND 38"



Roof Goose Vent LLC
SUPERIOR VENT TERMINATIONS

Roofgoosevent.com

P: 401-522-9857

Parts Included



- #1 Sleeve
- #2 Provided Insulation
- #3 Rain Collar
- #4 Duct Riser Clamp
- #5 6" S.S. Hose Clamp 5/16 Head
- #6 4" S.S. Hose Clamp 5/16 Head
- #7 (2) 4 Inch - 6 Inch Bushings
- #8 (4) 6" Screw Lags 5/16 Head
- #9 Roof Gooseneck

Step 1

Install Duct Riser Clamp (#4) Requires #8x3/4" Screws Field Supplied Plumb & Level



Step 2

Verify Duct Is 38"-39" Above Roof Membrane Or 27"-28" Depending On Sleeve Length



Step 3

For Temporary Water Protection Caulk Opening Around Duct



Step 5

Slide Provided Insulation (#2) Over Duct

Step 6

Slide Included Sleeve (#1) Over Duct Till Fully Engaged with Bushing



Step 6 Close Up

Sleeve Fully Engaged In Bushing

Step 7

Lace 6" S.S. Hose Clamp (#5) Through Rectangular Slots at Base of Sleeve (#1). Tighten Until Sleeve Is Firmly in Position



Step 7 "Front" Close Up



Step 7 "Side" Close Up



Step 4

Slide (1) Of The Included Bushings (#7) To The Base Of The Duct, Secure As Shown With Provided 4" S.S. Hose Clamp (#6) And Secure (4) 6" Screws (#8) To Roof Deck. *Take Caution To Not Over Tighten The Screws* If Underlying Duct Has Been Flashed Already 6" Screws Are Not Used.



SEE BACK FOR FURTHER INSTRUCTIONS

RG4-INSULATED INSTALL INSTRUCTIONS 27" AND 38"



Roof Goose Vent LLC
SUPERIOR VENT TERMINATIONS

Roofgoosevent.com

P: 401-522-9857

Step 8

Place (1) Of The Included Bushings (#7) On The Open End Of The Termination, Align Notches On Bushing With Locks On Tube



Step 9

Roofers Flashing Will Adhere To Sleeve (#1)



Step 10

Slide Rain Collar (#3) Down Sleeve Until It Covers Roofers Flashing (A Shimmy Motion Helps If Its Tight)



Step 11

Install Gooseneck (#9) With A Down, Clockwise, Down Motion Until Lock Fully Engaged At All 4 Points (See Steps 11.1-11.3 For Guidance)



Step 11.1

Align Internal Pegs Of Neck To Channels On Top Of The Sleeve Then Push Down



Step 11.2

After Step 12.1 Twist The Neck In A Clockwise Motion



Step 11.3

After Step 12.2 Push the Neck Down Until Lock Fully Engaged At All 4 Points

